


Nº	CODE	DESCRIPTION
1	BCL1501	CHAIN PROTECTION COVER ASSY
2	BCL1502	CHAIN GUIDE
3	BCL1503	38 LINK CHAIN
4	BCL1504	SPROCKET ASSY
5	BCL1505	SHIELD ASSY
6	BCL1506	TEETH ASSY
7	BCL1507	TENSION MECHANISM ASSY
8	BCL1508	GEAR BOX ASSY
9	BCL1509	WORM ASSY
10	BCL1510	GASKET
11	BCL1511	OIL PIPE ASSY
12	BCL1512	OIL PUMP ASSY
13	BCL1513	SMALL UMBRELLA ASSY
14	BCL1514	PLASTIC CASE ASSY
15	BCL1515	MOTOR ASSY
16	BCL1516	OIL TANK LID ASSY
17	BCL1517	OIL TANK ASSY
18	BCL1518	TRIGGER BUTTON SWITCH ASSY
19	BCL1519	MAIN PCB ASSY
20	BCL1520	DISPLAY ASSY
21	BCL1B08IB	BATTERY ASSY
22	BCL1C5IB	CHARGER



BAHCO

BCL15IB BCL15WB

Revision: 00

SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe

4042022